

# Coniston(White shown) Windermere (Grey) Bedroom Range



**3ft Single**  
W105 x L205 x H120cm  
**4ft 6 Double**  
W150 x L205 x H120cm  
**5ft Kingsize**  
W165 x L215 x H120cm  
**6ft Superking (Order only)**  
W193 x L215 x H120cm

**Cheval Mirror**  
W50 x D6 x H150cm



**Wall Mirror**  
W80 x D3 x H60cm



**Trinket Mirror**  
W55 x D12 x H62cm



**Dressing Table**  
W110 x D42 x H85cm



**Stool**  
W45 x D40 x H48cm



**Small Bedside**  
W40 x D32 x H58cm



**Large Bedside**  
W45 x D38 x H65cm



**X Large Bedside**  
W55 x D40 x H65cm



**3 Drawer Chest**  
W75 x D40x H80cm



**6 Drawer Chest**  
W130 x D42 x H85cm



**4 Drawer Narrow Chest**  
W55 x D40 x H100cm



**2 Over 3 Chest**  
W90 x D42 x H100cm



**Ladies Robe**  
W95x D56 x H185cm



**Large 2 door robe**  
W110 x D56 x H195cm



**Single robe**  
W70 x D56 x H195cm



**Large 3 door robe**  
W145 x D56 x H195cm



### **Coniston/Windermere Bedroom Range** this is a range name Specific to Westbridge Furniture Designs Ltd

Congratulations on buying your furniture, you have received a piece of furniture to be proud of. Taking good care of your furniture ensures its longevity.

## CARING FOR YOUR FURNITURE

### General Care

- Dust frequently with a cloth that attracts rather than scatters dust.
- Any objects on the surface need to be moved regularly to avoid shading. i.e. Lamps etc...
- Never leave spillages. Remove them immediately with a blotting action.
- When writing, a protective mat should be used to protect the surface from marking.
- Furniture will endure most temperatures in the modern home. However it should be positioned as far away from radiators, direct sunlight or other forms of direct heat sources, as possible.
- Avoid extremes in humidity. This can cause wood to warp and loosen glues. Keep furniture away from air conditioning units.
- The Furniture should not be used for sitting or standing on. (With the obvious exception of sitting on chairs and stools)
- It is always advisable to level furniture when placing it. This will ensure wardrobe doors are level and also removes undue pressures on joints.
- Never drag furniture - always lift it. **(NB Extending Tables Should be Lifted by the Frame not the Table Top)**

### Metal Handles and Fittings.

Metal polish should not be used as the fittings have their own protective lacquer to prevent tarnishing.

### Painted Finishes.

- Artificial distressing is created by hand to enhance the character of this range. It will vary in its position.
- Hairline cracks on the joints of timber are unavoidable due to movements in the timber frame
- Use only a slightly dampened cloth to clean. Cleaning products may damage the painted finish

### Lacquered wood Tops.

- A gentle wipe with a lint free cleaning cloth, in the direction of the grain, is all that is required to maintain the appearance of the lacquered wood.
- Made from Solid Wood and Veneers selected for their natural beauty. Wood is a unique product, and as such no two sections of the furniture are identical in Grain, Knots, Pattern or colour.