

Derwent and Ullswater Dining and Occasional Range



1.2m Butterfly Extending Table
120 x 85 x 78 cm



1.8m Butterfly Extending Table
180 x 100 x 78 cm



Cross Back Dining Chair
43 x 50 x 97 cm



Nest of 2
42x34x62cm



Large Coffee Table
100 x 60 x 45 cm



Round Nest of 2
52x52x60cm



Small Coffee Table
90 x 50 x 45 cm



Small Wide Bookcase
90 x 30 x 90 cm



Large Sideboard
140 x 40 x 85 cm



Standard Sideboard
100 x 40 x 85 cm



Small Sideboard
85 x 35 x 80 cm



Lamp Table
38 x 35 x 65 cm



Standard TV Unit
110 x 40 x 65 cm



Large TV Unit
150 x 40 x 65 cm



Corner TV Unit
100 x 50 x 65 cm



Hall Bench Unit
110 x 40 x 60 cm



Large Wide Bookcase
90 x 30 x 180 cm

Ullswater and Derwent Range this is a range name Specific to Westbridge Furniture Designs Ltd

Congratulations on buying your furniture, you have received a piece of furniture to be proud of. Taking good care of your furniture ensures its longevity.

CARING FOR YOUR FURNITURE

General Care

- Dust frequently with a cloth that attracts rather than scatters dust.
- Any objects on the surface need to be moved regularly to avoid shading. i.e. Lamps etc...
- Never leave spillages. Remove them immediately with a blotting action.
- When writing, a protective mat should be used to protect the surface from marking.
- Furniture will endure most temperatures in the modern home. However, it should be positioned as far away from radiators, direct sunlight or other forms of direct heat sources, as possible.
- Avoid extremes in humidity. This can cause wood to warp and loosen glues. Keep furniture away from air conditioning units.
- The Furniture should not be used for sitting or standing on. (With the obvious exception of sitting on chairs and stools)
- It is always advisable to level furniture when placing it. This will ensure wardrobe doors are level and also removes undue pressures on joints.
- Never drag furniture - always lift it. **(NB Extending Tables Should be Lifted by the Frame not the Table Top)**

Metal Handles and Fittings.

Metal polish should not be used as the fittings have their own protective lacquer to prevent tarnishing.

Painted Finishes.

- Artificial distressing is created by hand to enhance the character of this range. It will vary in its position.
- Hairline cracks on the joints of timber are unavoidable due to movements in the timber frame
- Use only a slightly dampened cloth to clean. Cleaning products may damage the painted finish

Lacquered wood Tops.

- A gentle wipe with a lint free cleaning cloth, in the direction of the grain, is all that is required to maintain the appearance of the lacquered wood.
- Made from Solid Wood and Veneers selected for their natural beauty. Wood is a unique product, and as such no two sections of the furniture are identical in Grain, Knots, Pattern or colour.